

Live it. Love it. Print it.

HP Sprocket Photo Printer



Perfectly portable



Add a personal touch



Printing just got social



With the HP Sprocket Photo Printer, you can conveniently print photos from your smartphone or tablet just as easily as you post them—and from virtually anywhere.¹ Make time with friends more memorable with instantly shareable 5 x 7.6 cm (2 x 3-inch) snapshots or stickers of every fun-filled moment.



Pocket-size printer

About the size of a smartphone, this Bluetooth® printer goes anywhere. It easily fits into a bag or backpack, and it's so light you'll barely notice it's there.



Prints with personality

Show off your creativity with filters, frames, stickers, text, emojis, and more.² The HP Sprocket App lets you customise your photos before you print them.



Easy social media printing

Easily print social media photos. Connect your social media accounts to the HP Sprocket App and instantly turn any of those photos into colourful prints.



Add a personal touch

Download the free and easy-to-use HP Sprocket App to customise your photos before you print them. Show off your creativity with filters, frames, stickers, text, emojis, and more. It's as easy as one, two, three!



1 Choose a photo

Snap a photo from your Android™ or iOS device, or select a favourite from your Camera Roll or social media accounts.



2 Personalise it

Get creative! If you want to, you can customise your photo before you print it.



3 Print and share

Print 5 x 7.6 cm (2 x 3-inch) stickable snapshots and share all the fun-filled moments. The rechargeable battery prints up to 30 sheets of photo paper per charge, and recharges in just 60 to 80 minutes.

Have fun with the easy-to-use HP Sprocket App

From the HP Sprocket App landing page, you can take a photo or select a photo from your Camera Roll or social media accounts.




Instagram

Facebook

Flickr

Camera Roll



You can easily customise your photo before you print. Tap the Edit button to add a filter, frame, stickers, text, emojis, or to crop your image.



Tap the Print button to instantly print your 5 x 7.6 cm (2 x 3-inch) photo. It's that easy!



Share your photos with friends. Tap the Share button and send your photos to multiple locations, including AirDrop, Facebook, text message, email, and more.

Printing just got more social



Share vibrant prints that capture all the fun-filled moments. The HP Sprocket App sets up easily and lets you and your friends and family quickly customise, print, and share photos.



Easy social media printing

Connect your social media accounts to the HP Sprocket App so you can easily snap, print, and share moments—as they happen!



Bluetooth connectivity

The HP Sprocket App instantly turns your social media photos into colourful prints. With seamless Bluetooth connectivity, your HP Sprocket Photo Printer can be the life of the party.²



Simply share

Easily share your photos with friends by sending them to multiple locations, including AirDrop, Facebook, text message, email, and more.

HP ZINK® Photo Paper

Instant.
Shareable.
Fun.



Easily load paper

Instantly print your favourite photos. The 5 x 7.6 cm (2 x 3-inch) size is perfect for sharing. Get started right away—the HP Sprocket Photo Printer comes with a 10-sheet pack of photo paper. Simply open the top of the printer, drop the paper in, and start printing!



Bright colours, durable prints

The HP Sprocket Photo Printer prints without ink, so the second your prints leave the printer, they're smudge-proof, water-resistant, tear-resistant and ready to be shared and handled. For best results, use HP ZINK® Photo Paper with the HP Sprocket Photo Printer: it's specially designed to ensure you get bright, glossy photos with vibrant colours every time you print.



Printable stickers

Just peel off the back of your prints and your photos become instant stickers. Decorate your bag, backpack, scrapbook, journal, bedroom walls, or anything in between with stickable snapshots of your favourite moments.

Get to know the HP Sprocket Photo Printer



Loop for personal charms, wrist strap, or clip
(not included with printer purchase)

Rear view



Ordering information

To order the HP Sprocket Photo Printer and supplies, please go to hp.com.
To contact HP by country, please visit hp.com/country/us/en/cs/contact-hp/contact.html.

If you don't have access to the Internet, contact your qualified HP dealer.



X7N07A

HP Sprocket Photo Printer
(white)



X7N08A

HP Sprocket Photo Printer
(black)



W4Z13A

HP ZINK®
Photo Paper

Notes

¹ On the go printing requires mobile device to be connected to HP Sprocket via Bluetooth® connection. Mobile printing from the HP Sprocket App is supported on iPhone and iPod touch on iOS v8.0 and higher. Android™ printing supported on Android devices using OS v4.4 and higher. For details on how to print, see hpsprocket.com. Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license.

² HP Sprocket App required.

Learn more at
hp.com



Share with colleagues



Rate this document

© Copyright 2016 HP Development Company, L.P. The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Bluetooth is a trademark owned by its proprietor and used by HP Inc. under license. AirDrop, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. Android is a trademark of Google Inc. ZINK® Technology and Zink® Trademarks are owned by Zink Holdings, LLC. Used under license.

